

Re-tuning: DAEWOO Freeview Recorders

9 Steps
(Steps 1-5)


This guide can be used to help you re-tune any of the following products with the remote control below:

DSD 9502 T, DSD 9503 T, DSD 9520,
DSD9503TFP, DSD9504TFP


**Make sure your box is on and press 80
for the BBC News channel**




- 1) Press the **Menu** button once




- 2) Use the **Down Arrow** to select **Setup** on the fifth line of the menu and press the **OK** button



- 3) Use the **Down Arrow** button to select **Installation** on the fourth line of the menu and press the **OK** button




- 4) Use the **Down Arrow** button to select **First Time Installation** on the fourth line of the menu and press the **OK** button



The message 'do you want to delete all channels...' will appear



- 5) **Don't worry!** Use the arrow buttons to select **Yes** and press the **OK** button




Manufacturer Helpline: **0844 887 2525**


email: **Online form at www.daewooelectronics.co.uk**

Re-tuning: DAEWOO Freeview Recorders



9 Steps
(Steps 6-9)





- 6) The message 'Hard drive is being initialised' will appear
- No action required




- 7) Press the **OK** button for a 4:3 TV or use the arrow buttons to select 16:9 for a widescreen TV and press the **OK** button



- 8) A re-tune screen will appear
- No action required



- 9) BBC1 will play out when the re-tune has completed
- No action required



You have completed the procedure and can continue viewing digital channels.

Manufacturer Helpline: **0844 887 2525**

email: **Online form at www.daewooelectronics.co.uk**