This guide can be used to help you re-tune any of the following products with the remote control below:

- *PFL5522D series, *PFP5532D series,
- *PFL5602D series, *PFL7662D series,
- *PFL7762D series
- * Your model size appears here

Make sure your box is on and press 80 for the BBC News channel





) Press the Digital Menu button





button to select
Installation on the
fifth line of the menu
and press the Right
Arrow button





3) Use the Down Arrow button to select Service Setup on the second line of the menu and press the Right Arrow button





4) Use the Down
Arrow button to
select Reinstall All
Services and press
the Right Arrow
button





5) Press the Zero button four times or enter your own PIN if you have changed it.



Manufacturer Helpline: 0800 331 6015

email: Online form at www.philips.co.uk

Re-tuning: PHILIPS Freeview TVs





6) Press the OK button to start the process



The message 'Do you really want to remove all services?' will appear



7) Don't worry!
 Press the OK button to confirm





B) A re-tune screen will appear

No action required





Press the OK button to store found services





 A 'please wait' message will appear on-screen

No action required




Manufacturer Helpline: 0800 331 6015

email: Online form at www.philips.co.uk

Re-tuning: PHILIPS Freeview TVs









12) Press the Digital Menu button to start viewing channels



You have completed the procedure and can continue viewing digital channels.

Manufacturer Helpline: 0800 331 6015

email: Online form at www.philips.co.uk