

# Re-tuning: **SAGEM** Freeview Recorders

7 Steps  
(Steps 1-5)


This guide can be used to help you re-tune any of the following products with the remote control below:

PVR 6200 - PVR7200 series  
DVR 6200 - DVR7200 series  
PVR 62160 - PVR72160 series  
DVR 62160 - DVR64250 series


**Make sure your box is on and press 80 for the BBC News channel**




- 1) Press the **M** (Menu) button once





- 2) Use the **Down Arrow** button to select the **Spanner** icon on the third line of the menu and press the **OK** button



- 3) Select **Channel Search** on the first line of the menu and press the **OK** button



- 4) A blue screen will appear asking you to start a new channel search. Press the **OK** button to confirm



- 5) A re-tune screen will appear  
No action required



Manufacturer Helpline: **0845 0900 316**

email: **support@sagemtechnical.com**

# Re-tuning: **SAGEM** Freeview Recorders

7 Steps  
(Steps 6-7)



- 6) You will be asked if you want to save the channel list. Select **Yes** and press the **OK** button



- 7) BBC 1 will automatically play out  
No action required



You have completed the procedure and can continue viewing digital channels.

Manufacturer Helpline: **0845 0900 316**

email: **support@sagemtechnical.com**