

# Re-tuning: **SAMSUNG** Freeview TVs

6 Steps  
(Steps 1-5)


This guide can be used to help you re-tune any of the following products with the remote control below:

LE\*R73BD series, LE\*S73BD series,  
LE\*R74BD series, LE\*S74BD series,  
LE\*R86BD series, LE\*S86BD series,  
LE\*R87BD series, LE\*S87BD series


**Make sure your box is on and press 80 for the BBC News channel**




1) Press the D. Menu button





2) Use the Down Arrow button to select the Channel Icon and press the Enter/OK button



3) Select Auto Store on the first line of the menu and press the Enter/OK button



4) A re-tune screen will appear  
  
No action required



5) BBC1 will automatically play out behind the menu when the re-tune has completed



Manufacturer Helpline: **0845 726 7864**

Website: **[www.samsung.com](http://www.samsung.com)**

# Re-tuning: **SAMSUNG** Freeview TVs

6 Steps  
(Steps 6-6)



- 6) Press the **D.Menu** button twice to close the menu and view channels



You have completed the procedure and can continue viewing digital channels.

Manufacturer Helpline: 0845 726 7864

Website: [www.samsung.com](http://www.samsung.com)