

Re-tuning: SONY Freeview Box


7 Steps
(Steps 1-5)

This guide can be used to help you re-tune the following product with the remote control below:



VTXD800U

Make sure your box is on and press 80 for the BBC News channel





- 



1) Press the Menu button


- 



2) Use the Down Arrow button to select Tuning on the fourth line of the menu and press the OK button


- 


3) Select Auto Tune on the first line of the menu and press the OK button


- 

4) Use the arrow buttons to select Yes and press the OK button


- 

5) Re-tuning screen
No action required



Manufacturer Helpline: 0845 6000 124

email: [Online form at www.sony.co.uk](http://www.sony.co.uk)

Re-tuning: **SONY** Freeview Boxes

7 Steps
(Steps 6-7)



6) Confirmation screen

Press the **OK** button to start viewing channels



7) BBC1 will automatically play out

No action required



You have completed the procedure and can continue viewing digital channels.

Manufacturer Helpline: **0845 6000 124**

email: **Online form at www.sony.co.uk**